www.bidet.com

uci
lifestyle upgrade

SUPREME BIDET SEA T

Installation Manual and Operating Instructions

BB-800, BB-900, BB-1000



- This Product should be installed according to this manual.
- Please read this manual carefully and install properly .
- Please keep this manual for future r eference.
- Please register Wa rranty for pr oper service.

UCI
lifestyle upgrade

SUPREME BIDET SEAT

Thank you for purchasing BIO BIDET(Supreme Bidet Seat).
This unit is manufactured for household use.

Contents

PREPARATION

- IMPORTANT SAFEGUARDS / GENERAL CAUTIONS 4
- CAUTIONS BEFORE INSTALLATION 6
- IDENTIFICATION 8

OPERATION

- OPERATION (BASIC) 9
- OPERATION (DETAILS) 10

INSTALLATION

- INSTALLATION 14
- DETACHMENT 17

MAINTENANCE

- MAINTENANCE 18
- WATER DRAINING 19
- TROUBLE SHOOTING 20
- SPECIFICATIONS 21
- INFORMATION TO THE USER 22
- WARRANTY 22

1 IMPORTANT SAFEGUARDS/GENERAL CAUTIONS

READ ALL INSTRUCTIONS BEFORE INSTALLATION AND USE

The following terms are used in this manual to indicate hazards of varying degrees of severity

DANGER	indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
WARNING	indicates potentially hazardous situation which, if not avoided, could result in death or serious injury.
CAUTION	indicates potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in damage to the product or other property.

DANGER - To reduce the risk of electrocution

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons

PLEASE OBSERVE THE FOLLOWING PRECAUTION BEFORE USING BIO BIDET (SUPREME BIDETSEAT)

Do not open the product to repair or remodel.
Only qualified service personnel should service BIO BIDET (SUPREME BIDET SEAT). Do not use attachments not recommended by the manufacturer.

Do not splash water on BIO BIDET(SUPREME BIDET SEAT).
Do not install in a location exposed to excessive moisture that condensation forms on the BIO BIDET(SUPREME BIDET SEAT) surface. To avoid damage to electronic components due to high levels of humidity, provide adequate ventilation opening via an opened window and/or door when bathing.



The BIO BIDET(SUPREME BIDET SEAT) must be grounded. Connect the grounding wire properly to the grounding terminal. Refer to the grounding instructions. An approved Ground Fault Circuit Interrupt (GFCI) must be used.

Do not touch the power cord with wet hands. Do not reach for a product that has fallen into water. Unplug immediately!



Do not plug in the power cord before connecting the water supply hose.



Connect the BIO BIDET(SUPREME BIDET SEAT) to cold water supply pipe carrying potable water. Do not connect to an industrial water supply line that does not carry water of drinking quality.
This will negatively effect hygiene and performance.



About Low Temperature Burns-
A burn occurs when the skin has been exposed to high temperatures. However, a low temperature burn may occur when the skin has been in contact with an object at relatively low temperature (about 104 °F).
Close supervision is necessary when this product is used by, on, or near children or invalids

Keep the cord away from heated surfaces. And keep any flammable materials away from the BIO BIDET(SUPREME BIDET SEAT)

If using any chemical toilet bowl cleaner, be sure to wipe up any spills that splash onto BIO BIDET(SUPREME BIDET SEAT). Do not use benzene or any acid chemical detergent. Only neutral detergent permitted.



Never operate this product if it has a damaged cord or plug. BIO BIDET(SUPREME BIDET SEAT) must be connected to a standard voltage power source. Do not connect power cord if the cord is damaged or broken. Do not plug the unit into a loose electric outlet.



Please disconnect the power cord when you clean the BIO BIDET(SUPREME BIDET SEAT) or detach it from toilet bowl. Do not supply electrical power to the unit until the plumbing installation work has been completed.



⚠ CAUTION

Never operate this product if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair

Do not obstruct or put anything into the dry air outlet. Do not apply excessive force to the shower nozzle.

Do not stand or sit on the seat coverlid. It is not designed to support a user's body weight.

Do not bang the seat and lid.

Do not strain or push the connected hose and tube connecter; it may cause water leakage. Never drop or insert any object into any opening or hose



Use BIO BIDET(SUPREME BIDET SEAT) only as described in the operating instructions. Never use while sleeping or drowsy. Do not use while bathing.

Be careful so that BIO BIDET(SUPREME BIDET SEAT) does not become stained with excrement and urine.

Drain the water from BIO BIDET(SUPREME BIDET SEAT) and unplug the power if it is not going to be used for an extended period of time. This will help prevent the unit from freezing over and in good condition.



- SAVE THESE INSTRUCTIONS -

2 CAUTIONS BEFORE INSTALLATION

WIRING REQUIREMENT

BIO BIDET(SUPREME BIDET SEAT) MUST BE PLUGGED into a regular voltage (North America 120V AC, 60Hz / Europe 230V AC, 50Hz) and the rated power consumption is 660W / 660W Grounded GFCI outlet. In locations where only a standard two-prong outlet is available, it is the responsibility of the user to install a grounded three-prong outlet.
Using a higher voltage is dangerous and may result in a fire or other accident. BIO BIDET is not responsible for damage resulting from the use of BIO BIDET(SUPREME BIDET SEAT) on other than specified voltage, or operating it without proper grounding.

⚠ WARNING	BIO BIDET(SUPREME BIDET SEAT) must be on a separated circuit. No other appliance should share the circuit with BIO BIDET(SUPREME BIDET SEAT). Sharing a circuit could cause the branch circuit fuse to blow or the circuit breaker to trip. Continuous usage under these conditions could result in fire or property damage.

GROUND INSTRUCTIONS

(1) BIO BIDET(SUPREME BIDET SEAT) has a three-prong grounding plug, which must be plugged into an outlet that is properly installed and grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.
If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.
Check with a qualified electrician or serviceman if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.

(2) This product is for use on a nominal 120V circuit, and has a grounding plug that looks like the plug illustrated in sketch A in Figure 1. A temporary adapter, which looks like the adapter illustrated in sketches B and C, may be used to connect this plug to a 2-pole receptacle as shown in sketch B if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (sketch A) can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by the screw.



- Figure 1-

⚠ DANGER	IMPROPER GROUNDING CAN RESULT IN A RISK OF ELECTRIC SHOCK. Electric wiring has to be done in accordance with all local codes, or in the absence of local codes, with the National Electrical Codes.

The use of an extension cord is not recommended or advised. If it is necessary to use an extension cord, use only a three-prong extension cord, and a three slot built-in GFCI receptacle that will accept the plug on BIO BIDET(SUPREME BIDET SEAT). The marked rating of the extension cord should be equal to or greater than the electrical rating of the unit (10amp). Consult a qualified electrician or service person if you are not sure whether the unit is properly grounded.

3 IDENTIFICATION

1 MAIN UNIT



2 ACCESSORIES


T-Valve and Washer


Washer
(2 pcs)


Deodorizer Filter Unit
(Use Semipermanent)


Water Supply Tube to
BIO BIDET(Shower Toilet Seat)

Water Supply Tube to
Toilet Fresh Tank


Cone Packing
(2 pcs)


DEODORANT
(CARBONATE)


Mounting Bolts 2 pcs


Nuts
(2 pcs)


Spanner

Simple Guide Sheet

Installation Instruction Sheet

User Operating Manual


Quick Release plate
(1 pc)


Bolt Guide
(2 pcs)

3/8" Spare Nut
(With Packing)

Remote control


Remote control Fixed Panel

Battery (2pcs)
1.5V AA

Fix screw &
Blocking (3pcs)

4 OPERATION (BASIC)



Simple Operation Panel



- **When you sit on the unit, please sit down on the central position in order to activate the sensor.**
- **After an extended wash, allow about three minutes for water to reheat.**

5 OPERATION (DETAILS)

1 PREPARATION

- Open the shut off valve and check for any water leaks.
- Plug the unit into the proper power source and turn it on.
- The water tank will be filled after pushing a "Wash" (or) button. When the water tank is filled, the buzzer sounds "Beep".

2 OPERATION

SIT DOWN ON THE SEAT

- When you sit down on the seat, the LED lamp on the control panel will light up.
- When the digital sensor on the seat is activated, the operation LED window on the unit will light "Occupied sensor"; simultaneously, Deodorizer will start working.

STOP

- Press this switch to stop in middle of operation.

CLEANSING

- **CLEANSING 1. (Posterior Wash)**

- Press "Posterior Wash"( ), automatically nozzle comes out and sprays warm water to posterior. If you press "Oscillation (Move)", the nozzle moves back and forth automatically. Nozzle stops moving when the switch is pressed again. It automatically stops after two minutes.

- **CLEANSING 2. (Enema Wash)**

STEP 1 : Press "Enema Wash"( ), automatically nozzle comes out and sprays.
STEP 2 : The stream of water is set to the posterior center.
STEP 3 : Press "water pressure-High & Low button"(,) and adjust the water pressure.
STEP 4 : If you feel that the water has filled you up a bit, just wait for a minute and push the water and feces out.

- If you do not push out the water in a rectum completely, you may feel unwell.

- **CLEANSING 3. (Feminine Wash)**

- Press "Feminine Wash"( ), automatically nozzle comes out and sprays warm water to feminine area. If you press "Oscillation (Move)", the nozzle moves back and forth automatically. Nozzle stops moving when the switch is pressed again and It automatically stops after two minutes.

WARM AIR DRYER

- Press "Dry( )", dry air comes out. Middle of operation, you can adjust the warm air temperature with "High( )" and "Low( )" button. It will automatically stop about 3 minutes later.

STOP

- Press this button to stop in middle of operation.

WATER PRESSURE ADJUSTMENT AND DRY TEMPERATURE ADJUSTMENT

- After sitting down on the seat, the LED lamp( ) for water pressure should light at 3 levels( ). You can adjust the water pressure with "High( )" and "Low( )" button. Adjust the "Warm Air Dryer" temperature with "High( )" and "Low( )" button. In addition, the unit memorizes the air temperature of prior use. Basically, the uint memorizes the water pressure level of prior use. (But, when user put the simple operation panel, the first water pressure always should be fixed on middle level)

CAUTION

When user does not use remote control for 10 seconds, the LED lamp will turned off in order to save the battery power.

WARM WATER TEMPERATURE AND SEAT TEMPERATURE ADJUSTMENT

- The temperature of water and seat are adjustable to the desired level by pressing 'WATER( )' and 'SEAT( )' button.



OPERATION

5 OPERATION (DETAILS)

NOZZLE POSITION ADJUSTMENT

- **Nozzle position is adjustable to the desired position by pressing "(Front) (FRONT)" or "(Rear) (REAR)" button from 1 to 5 positions. After using product, the nozzle should return to position 3.**

DEODORIZER

- **The deodorizer is activated when the unit is occupied. After using the unit, it will automatically stop about 1 minute later.**
- **The deodorized air velocity of wind is adjustable to the desired level by pressing "STOP"(■) and "WATER"(WATER), simultaneously.**

■ + WATER

(Level1~4)



OFF	Deodorizer (Air velocity of wind)	Deodorizer (Air velocity of wind)	Deodorizer (Air velocity of wind)
	On Using → Low Speed	On Using → Low Speed	On Using → High Speed
	After using → Low Speed	After using → High Speed	After using → High Speed

OSCILLATION (Nozzle Move Function)

- **When using Posterior or Feminine Washing, press in a "OSCILLATION (Move)" button will provide oscillating spray for much wider cleansing. This function is not available during Enema Wash.**
- **In addition, the oscillation can be adjusted to the desired position by pressing "OSCILLATION (Move)" and "(FRONT)(Front) or (REAR) (Rear)", simultaneously.**
- **If you push "OSCILLATION (MOVE)" again, the oscillation will be stop automatically.**

*** Auto-Setting of Oscillation**

: Without being occupied, press "OSCILLATION (MOVE)" button for 3 seconds to set up "Auto-Setting of Oscillation".

*** Auto-Setting of Oscillation**

: Without pushing "Move" button, when using Posterior or Feminine Washing, this oscillation function will be operated automatically.

6 INSTALLATION

⚠ CAUTION BEFORE INSTALLATION

- **Please, do not plug in before installation.**
- **If you need an electric power system or extension, please consult a qualified electrician.**

STEPS

1 **Shut off the water supply to the existing toilet tank by closing the angle stop valve. Drain the toilet tank completely. Remove the water supply hose to toilet tank.**



2 **Removing the existing seat and lid.**

- By using a wrench (spanner) or other proper tool, release the nut on both sides of existing toilet to remove the toilet seat and lid.

3 **Connect T-Valve.**

- Remove existing supply tube from fresh tank
- Angle Stop Valve is standard 1/2" in size. If it is 3/8"use the 1/2"to 3/8"conversion nut kits with packing before connecting the Angle Stop valve. Install T-Valve on top of Angle Stop Valve.



4 **One of flexible tube connects from top of T-Valve to toilet tank.**



INSTALLATION

MASSAGE (Rhythmic Wash)

- **When using Posterior Wash, Enema Wash or Feminine Washing, pressing "MASSAGE (Rhythmic Wash)" button will provide pulsating spray. In addition, the water pressure is adjustable by pushing "(HIGH) High or (LOW) Low" and "MASSAGE", simultaneously.**

*** Auto-Setting of Massage**

: Without being occupied, press "MASSAGE" button for 3 seconds to set up Auto-Setting of "MASSAGE".

*** Auto-Setting of MASSAGE**

: Without pushing "MASSAGE" button, when using CLEANSING, this Massage function will be operated automatically.

ECONOMY (Power Save Mode)

- **ECONOMY 1: The "ECONOMY 1" feature drops the water temperature and seat temperature to about 32°C (90°F) when the seat is not in use.**
- **ECONOMY 2: The "ECONOMY 2" (Intelligent Economy Function) records the main time the family use it, for 4 days after installation. Then the unit sets up the "Power-On and Off Time". The "ECONOMY 2" feature drops the water and seat temperature to about 32°C (90°F). When the seat is in use during this mode, the settings are returned to their original levels. After using, the unit is returned to "ECONOMY Mode".**

NOZZLE CLEANING (Automatic)

- **BIO BIDET(SUPREME BIDET SEAT) has an automatic nozzle self-cleaning function that works before and after each operation.**

NOZZLE CLEANING (Manual)

- **Nozzle can be cleaned manually by pressing "CLEANSING 1: Posterior Wash( )" button for 3 seconds without being occupied on the seat and nozzle will come out. Press "CLEANSING 1: Posterior Wash( )" button for 3 seconds again to return nozzle to stand- by mode.**

5 Place bolt guide with bolt in quick-release plate and slide into designated groove at rear bottom of main body.



6 Place main unit aligning to toilet seat mounting holes.



7 Securly tightening mounting bolts with supplied cone packing and plastic washer.



8 Connect water supply flexible hose to the unit.



INSTALLATION

* Connect ground wire from T-Valve to BIO BIDET(SUPREME BIDET SEAT).
* Check for any water leakage.

6 INSTALLATION

9 Insert the deodorant catalyst into the unit.



How to change the deodorant catalyst

1 Check the deodorant package.



Deodorant.



Deodorant case

Cover

2 Follow the below photos to change the deodorant.



3 Insert the new deodorant case into the unit.



10 Installation of Remote Control.



Peel off adhesive protection to use self-adhesive.

Or, mount on the wall using supplied screws.

Screw mounting holes.



Place supplied batteries and close the cover.

7 DETACHMENT

If you move or clean the toilet, please separate the BIO BIDET (SUPREME BIDET SEAT) from toilet bowl.

1. **Disconnect power.**
2. **Shut off water supply.**
3. **Empty water tank using drainage.**
4. **Slide out main unit from quick release plate while pushing drainage as illustrated below.**



⚠ Do not turn upside down.



5. **Disconnect the tube and T-Valve from unit (Refer to page # 14).**

8 MAINTENANCE

CLEANING THE NOZZLE

- When the "Posterior Wash( )" button(in simple operation panel) is pressed for 3 second without occupying the seat, the nozzle can be cleaned with a toothbrush.
- After cleaning the nozzle, push the "Stop( )" button (in simple operation panel) once again, and the nozzle retracts itself.



CLEANING THE BODY OF UNIT

- When you clean the body, do not use "thinner", "benzene" or "NaClO". It causes defects to the surface of unit.
- Please use a wet cloth when you clean the unit.
- Do not spray water directly on the unit.
- When you clean the unit, please disconnect the power plug.

CLEANING THE STRAINER

The product {BIO BIDET(SUPREME BIDET SEAT)} will not operate properly if the strainer is clogged. Please clean the strainer regularly.

1) Close the shut off valve.
2) Flush the toilet to empty the water reservoir.
3) Unscrew the water filter nut.
4) Clean the strainer with a small brush or water.
5) Re-screw the water filter nut.
6) Open the shut off valve.



9 WATER DRAINING

DRAIN THE WARM WATER TANK IN THE UNIT

If you do not use the product for long time, please drain water from the warm water tank.

1) Disconnect the power plug.

2) Close the shut off valve.



3) Press the drain lever until the water is completely drained from the unit's water tank.

4) To re-supply water after draining, open the shut off valve.

Do not drink the drained water.
Do not insert finger into the drain hole.
Before draining, unplug the power cord and wait 30 minutes until the unit has cooled down.

MAINTENANCE FOR WINTER SEASON

1. **Please check the power cord whether plugged in or not.**
2. **Keep the water temperature on "Middle or High Level" to prevent water from freezing.**
3. **If you do not use the unit for long time, please disconnect the power plug and drain the water.**

10 TROUBLE SHOOTING

Trouble	Cause	Remedy
The washing water is not sprayed	1.The water tank is not filled. 2.The shutoff valve is closed. 3. Freezing inside the main unit or the water supply pipe.	1. Wait about one minute. 2.Press the desired washing button once again. 3.Turn on the shutoff valve to open. 4.Heat the room (for about two hours). Operating the unit while parts are frozen will cause a malfunction.
The unit is not operating	1.Disconnected the power cord. 2.The seat is not occupied. 3. The battery of remote controller is exhausted.	1.Connect the power cord. 2. Check the power supply system in your house. 3.Occupy the seat (The unit has an occupied sensor). 4.Replace the battery.
Water is leaking	1.Check the water supply system	1. If water is leaking from the main unit, call the service center or the place you purchased.
The washing water pressure is weak	1.The water pressure level is set to "LOW". 2.The strainer is clogged.	1.Set the water pressure to "HIGH". 2.Clean the strainer.
The washing water is not warm	1.The water temperature is set to "LOW". 2.Continuous operation has depleted the supply of warm water.	1.Set the water temperature to "HIGH" 2. Wait about three minutes.
The seat and dryer is not warm	1.The seat & dryer temperature is set to "LOW"	1. Set the seat & dryer temperature to "HIGH".

11 SPECIFICATIONS

Specifications		BB-1000	
Power Rating		AC 120V 60Hz 660W	
Water inlet type	Type	Direct Inlet flow type	
	Water inlet pressure	0.4 ~ 7.5 kgf/cm²(5.69 psi ~ 106.7psi)	
Power cord		1.2m (4 feet)	
Wash Device	Posterior Wash	Max. 1.2 ℓ /min (Max. 0.32 GPM)	
	Feminine Wash	Max. 1.2 ℓ /min (Max. 0.32 GPM)	
	Water Pressure Adjustable	5 Levels	
	Warm Water Temperature	Room Temp - 40°C (Room Temp. 104 °F)	
	Heater	600 W	
	Safety Devices	Thermal fuse, Thermal switch, Float switch	
Heated Seat	Temperature	Room Temp ~ 41°C (Room Temp. ~ 105.8°F)	
	Heater	55W	
	Safety Device	Thermal fuse	
Warm Air Dryer Device	Adjustable Dry Temperature (Room Temp~45 °C)	○	
	Heater (250W)		
	Safety Device (Themal fuse, bimetal)		
Enema Function		○	
Deodorizer		○	
Remote control		○	
Inlet water temperature		3°C ~ 35°C (37.4 °F ~ 95 °F)	
Ambient Temperature		3°C ~ 40°C (37.4 °F ~ 104°F)	
Dimension		Elongated	Round
		W : 475mm (18.7 inch) L : 525mm (20.6 inch) H : 185mm (7.28 inch)	W : 475mm (18.7 inch) L : 493mm (19.4 inch) H : 185mm (7.28 inch)
Weight (kg, lbs)		5.2kg (10.7 lbs)	

12 INFORMATION TO THE USER

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

• **OR**

"Note : The manufacturer is not responsible for any Radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment."

13 WARRANTY

UCI, Inc.
Limited Warranty

This limited warranty gives you specific legal rights, and you may also have other rights that may vary from state to state or according to other conditions.

General Limited Warranty Covered The Manufacturer, UCI, Inc will warrant to the original retail buyer only, which fails in normal use and within the applicable periods specified below, following the terms of this warranty. UCI, Inc replacement will be warranted to the original purchaser of the products.

The Parts Warranty If the parts fail within Twelve (12) months after original installation following the installation manual and normal operation, UCI, Inc will furnish a replacement part(s).

Will be not Covered by this Warranty

1. Defects and/or malfunctions from failure to properly install, operate and/or maintain the unit in accordance with the installation manual.
2. Damage from abuse, fire, flood, freeze, and any other act of God.
3. Damage resulting from unauthorized alterations, attachments and/or repairs.
4. If the product was not installed properly to residential water closets.
5. Damage from installing the unit in an environment with animals, mice or insects.
6. Damage caused by excess moisture or from water clogging the water closet.
7. Damage from not being installed in accordance with all applicable local codes, ordinances and good trade practices.
8. Color fading due to use in wrong environments.
9. Damage from consumable chemicals.
10. The warranty will not be covered without providing the date of purchase with original receipts.
11. Damage from misuse due to not following the installation manual.

WARRANTY REGISTRATION

To ensure your warranty protection you must complete and return this card to UCI, Inc within 10 days after date of purchase.

Model _____ **Serial Number #** _____

Purchaser

_____

company _____

Address _____

City _____ **Country** _____

Phone _____ **Fax** _____ **E-mail** _____

Dealer(Company)

_____ **Dealer Code** _____

Address _____

_____

PLACE STAP HERE

Service Department

Head office:
205 Berg Street
Algonquin, Illinois 60102
Tel: (847) 854-7292
Fax: (847) 854-1296

MAINTENANCE

UCI

lifestyle upgrade

www.biobidet.com

Manufacturer

UCI, Inc.

Head office:
205 Berg Street
Algonquin, Illinois 60102
Tel: (847) 854-7292
Fax: (847) 854-1296